

# Is your Battery Pack ON?



Press & **HOLD**  
this button  
to turn it **ON**.



When your battery  
is OFF or DEAD  
you'll see this warning



Press & HOLD the button  
to turn your battery back ON.

Battery dead? Get a new one from the charging station.  
Look for 4 lights when you tap the button.

**The Battery Pack is your Key to Wifi Connection**

Always Connected  Always Protected